



TEMPORARY ROCK DITCH CHECKS IN ROADSIDE DITCHES

NOTES:

1. ROCK FILTER DAMS (RFD) MAY BE USED AS A DISCHARGE STRUCTURE WHILE WORKING WITH HIGHLY EROSIVE SOIL. RFD's MAY BE USED AS PART OF A "BMP TRAIN" AND MAY BE USED IN SUCCESSION AT A MINIMUM SPACING OF 100 FT OR PER THE EROSION CONTROL PLAN APPROVED BY THE ENGINEER.
2. SIZE 300 LB RIP RAP MAY BE USED FOR SPECIFIED APPLICATIONS AS SHOWN ON EROSION CONTROL PLAN.
3. SEDIMENT CONTROL STONE SHALL BE PLACED BETWEEN 1/3 AND 1/2 UP THE FACE OF THE RIP-RAP FROM THE GROUND.
4. THE COST OF THE FABRIC SHALL BE INCLUDED IN OTHER ITEMS BID.

10/5/2015 11:48 AM ECD-9.DGN

MISSISSIPPI DEPARTMENT OF TRANSPORTATION	
ROCK FILTER DAM	
PRELIMINARY NOT FOR CONSTRUCTION	
COUNTY:	WORKING NUMBER
PROJ. NUM.:	ECD-9
FILENAME: ECD-9.DGN	SHEET NUMBER
DATE	\$PG\$
DESIGN TEAM	CHECKED DATE 9/29/15